



Syncontrol battery charging and maintenance instruction

Before using the battery pack, it must be activated by plugging in the charger for a few seconds. Thereafter the battery is activated and will react on the push button of the battery pack. In the activated state, the standby power consumption is higher than in the ship mode state!

For transportation purposes the state of charge of the battery pack has to be very low. Therefore, the battery is supplied in the shipping mode state, which insures the lowest power consumption. In this state the battery can be stored for up to 3 months.

After that, the battery pack has to be charged to between 50% and 75 % (2 or 3 lighted LEDs) before longer storage to avoid deep discharge of the battery! This also applies if the battery pack is installed to a table and will not be used for a longer period of time.

Should the battery be stored for a longer period of time after charging, it is strongly recommended to put the battery pack into ship mode again by pressing the push button on the battery pack **for 5 seconds** until the LEDs no longer light up. After that, the battery pack will not react on pushing the button anymore!

Following these rules will ensure a long life of the battery pack and enable maximum standby and storage periods!

No warranty can be granted in case of non-compliance with these regulations!